



**ASSA ABLOY**

Experience a safer  
and more open world

## **INSTALLATION INSTRUCTIONS**

Positive Pressure (UL 10C) Labeled Door

THIS DOOR HAS BEEN LABELED FOR COMPLIANCE WITH UL10C. IT DOES NOT REQUIRE THE APPLICATION OF AN ADDITIONAL INTUMESCENT EDGE-SEALING SYSTEM. TO MAINTAIN THE VALIDITY OF THIS CERTIFICATION, THE DOOR INSTALLER MUST FOLLOW THESE INSTRUCTIONS. THEY SHOULD BE KEPT ON FILE ON THE BUILDING PREMISES FOR VERIFICATION BY THE AUTHORITY HAVING JURISDICTION.

- 1. Verify that frame is compatible with door and properly installed. See item #4 if smoke & draft control is required.**
- 2. Install hardware per hardware manufacturer's instructions.**
- 3. Install lite kit (if required) per lite kit manufacturer's instructions. The lite kit must be a Listed UL 10C fire rated lite kit. When installed in a smoke & draft control assembly, the perimeter of the glazing material and vision panel frames shall be sealed to resist the passage of smoke at temperatures up to 400°F (204°C) per NFPA 105 Sec 6.4.2**
- 4. When smoke & draft control rating (S Mark) is required, a fire-rated smoke and draft control gasket shall be installed in the opening. Listed Category H Smoke and Draft gasket or gasket packaging is to be labeled as Category H Gasket. Install gaskets per manufacturer's instructions. Gasketing system must be compatible with the door and frame type.**
- 5. Installation must comply with requirements of NFPA80.**